



DF-U


Electronic sensor




TECHNICAL CHARACTERISTICS

10-30 V DC
<30 mA
30 mA
<3,5 V DC
PNP N.O.
green (power)
red (close)
yellow (open)
IP 67
39x49x31 mm
100 gr





B-B(1:1)





Male contacts Micro C M12

How to replace the sensor

Unscrew the 2 screws and replace the sensor.

Orientation of the connector

- Unscrew the screw which tightens the support of the connector and turn it to the 90° position.
- Reposition the support of the connector.
- Tighten the screw.



